#### **Table of Contents**

Title: IMAGE MANIPULATION WITH MATLAB
Author: Filippo Valmori
Date: 21/03/2023
Reference: [1] Digital signal processing - Fundamentals and applications (Li Tan, 2013) [Ch.14]
PARAMETERS
PROCESSING
RESULTS

# Title: IMAGE MANIPULATION WITH MATLAB

**Author: Filippo Valmori** 

Date: 21/03/2023

Reference: [1] Digital signal processing - Fundamentals and applications (Li Tan, 2013) [Ch.14]

```
close all
clearvars
clc
```

### **PARAMETERS**

## **PROCESSING**

```
Xequal = histeq(Xgrey,Nbins);
      % Equalize grey-scale image
[Xidx,Map0] = rgb2ind(Xrgb,Nclr);
      % Convert RGB to indexed-color image and extract color-map
MapG = Map0;
      % Create green color-map
MapG(:,1) = 0;
      % Remove red tones (R) from color-map
MapG(:,3) = 0;
      % Remove blue tones (R) from color-map
MapV = MapO;
     % Create violet color-map
MapV(:,2) = 0;
      % Remove green tones (R) from color-map
KernL = fspecial('log',SzK,Sigma);
      % Get Laplacian of Gaussian kernel for edge filtering
Xedge = filter2(KernL,im2double(Xgrey));
      % Convert grey-scaled image to double precision and then filter
```

## **RESULTS**

```
figure('Name','1. COLOR FILTERING','NumberTitle','off')
subplot(2,2,1)
imshow(Xrgb)
title('Original RGB')
subplot(2,2,2)
imshow(Xidx,MapO)
title(sprintf('Color-compressed (%d)',Nclr))
subplot(2,2,3)
imshow(Xidx,MapG)
title('Color-filtered (Green)')
subplot(2,2,4)
imshow(Xidx,MapV)
title('Color-filtered (Violet)')
figure('Name','2. EQUALIZATION','NumberTitle','off')
subplot(2,2,1)
imshow(Xgrey)
title('Gray')
subplot(2,2,2)
imshow(Xequal)
title(sprintf('Equalized-Gray (%d)',Nbins))
subplot(2,2,3)
imhist(Xrqb)
title('Histogram before equalization')
subplot(2,2,4)
imhist(Xequal)
title('Histogram after equalization')
figure('Name','3. EDGE FILTERING','NumberTitle','off')
```


Original RGB




Color-compressed (4)



Color-filtered (Green)





Color-filtered (Violet)



Gray

Equalized-Gray (10)







Published with MATLAB® R2022a